

Nighat Yasmin Ph.D.

# Introduction to AutoCAD® 2018 for Civil Engineering Applications

Learning to use AutoCAD for Civil Engineering Projects



Better Textbooks. Lower Prices.  
[www.SDCpublications.com](http://www.SDCpublications.com)

Visit the following websites to learn more about this book:



# TABLE OF CONTENTS



|  |           |
|--|-----------|
| <b>1. INTRODUCTION TO ENGINEERING GRAPHICS.....</b>  | <b>1</b>  |
| 1.1. LEARNING OBJECTIVES .....   | 1         |
| 1.2. ENGINEERING PROBLEM.....  | 2         |
| 1.3. TECHNICAL DRAWING.....  | 2         |
| 1.4. DRAWING METHODS .....   | 2         |
| 1.5. DRAWING STANDARDS.....  | 4         |
| 1.6. SCALE .....   | 4         |
| 1.6.1. <i>Type of scale</i> .....  | 4         |
| 1.6.1.1. Representative Fraction.....  | 4         |
| 1.6.1.2. Equivalence relation.....   | 5         |
| 1.6.1.3. Converting RF to ER.....  | 5         |
| 1.6.1.4. Graphical representation .....  | 6         |
| 1.7. SCALE OF A DRAWING.....   | 7         |
| 1.7.1. <i>Full scale</i> .....   | 7         |
| 1.7.2. <i>Large scale</i> .....  | 7         |
| 1.7.3. <i>Small scale</i> .....  | 7         |
| 1.8. COMPUTER AIDED GRAPHICS.....  | 8         |
| 1.8.1. <i>AutoCAD 2018</i> .....   | 8         |
| 1.8.2. <i>AutoCAD and drawing scale</i> .....  | 8         |
| <b>2. GETTING STARTED WITH AUTOCAD 2018 .....</b>  | <b>11</b> |
| 2.1. LEARNING OBJECTIVES .....   | 11        |
| 2.2. INTRODUCTION.....   | 12        |
| 2.3. FOCUS OF THE BOOK .....   | 17        |
| 2.4. INITIAL SETUP .....   | 17        |
| 2.5. TYPICAL WINDOW SCREEN .....   | 18        |
| 2.6. DRAWING AREA .....  | 19        |
| 2.6.1. <i>Model space</i> .....  | 21        |
| 2.6.2. <i>Layout</i> .....   | 22        |
| 2.6.3. <i>Display/hide Model and Layout tabs</i> .....   | 23        |
| 2.7. STATUS BAR.....   | 24        |
| 2.8. THE CURSOR .....  | 26        |
| 2.8.1. <i>Location of the cursor</i> .....   | 27        |
| 2.8.2. <i>Size of the intersecting lines</i> .....   | 27        |
| 2.8.3. <i>Size of the aperture</i> .....   | 28        |
| 2.8.4. <i>Color of the cursor</i> .....  | 28        |
| 2.9. WORLD COORDINATE SYSTEM (WCS).....  | 29        |
| 2.10. SCROLL BARS.....   | 30        |
| 2.11. VIEWCUBE  ..... | 30        |
| 2.11.1. <i>ViewCube settings</i> .....   | 31        |
| 2.11.2. <i>View switching</i> .....  | 32        |
| 2.12. DRAWING DISPLAY FORMAT.....  | 33        |
| 2.13. COMMAND LINE WINDOW .....  | 35        |
| 2.13.1. <i>Move the CLW</i> .....  | 35        |
| 2.13.2. <i>Display/hide the CLW</i> .....  | 36        |
| 2.13.3. <i>Resize the CLW</i> .....  | 37        |
| 2.13.4. <i>Change the color of the CLW</i> .....   | 37        |
| 2.13.5. <i>Change the font of the CLW</i> .....  | 38        |

|           |  |           |
|-----------|--|-----------|
| 2.14.     | RIBBON.....  | 39        |
| 2.14.1.   | <i>Color scheme</i> .....  | 40        |
| 2.14.2.   | <i>Relocate</i> .....  | 40        |
| 2.14.3.   | <i>Hide/Display a ribbon</i> .....   | 42        |
| 2.14.4.   | <i>States</i> .....  | 45        |
| 2.14.5.   | <i>Ribbon's Tab</i> .....  | 46        |
| 2.14.5.1. | Display/Hide Tabs .....  | 46        |
| 2.14.5.2. | Tab relocation.....  | 47        |
| 2.14.5.3. | New tab.....   | 47        |
| 2.14.6.   | <i>Ribbon's panel</i> .....  | 53        |
| 2.14.6.1. | Panel components .....   | 53        |
| 2.14.6.2. | Display/Hide panel.....  | 54        |
| 2.14.6.3. | Panel relocation.....  | 55        |
| 2.14.6.4. | Floating panel .....   | 56        |
| 2.14.6.5. | Create new panel.....  | 57        |
| 2.14.6.6. | Add panel to a tab .....   | 60        |
| 2.14.6.7. | Add commands to a panel.....   | 60        |
| 2.15.     | WORKSPACE.....   | 66        |
| 2.15.1.   | <i>Save a workspace</i> .....  | 66        |
| 2.15.2.   | <i>Rename a workspace</i> .....  | 67        |
| 2.15.3.   | <i>Switch a workspace</i> .....  | 69        |
| 2.15.4.   | <i>Delete a workspace</i> .....  | 69        |
| 2.16.     | BASICS OF A DRAWING FILE.....  | 70        |
| 2.17.     | NEW DRAWING  .....  | 71        |
| 2.18.     | DRAWING'S NAME .....   | 74        |
| 2.19.     | DRAWING UNITS .....  | 75        |
| 2.19.1.   | <i>Length</i> .....  | 76        |
| 2.19.2.   | <i>Angle</i> .....   | 77        |
| 2.19.3.   | <i>Insertion scale</i> .....   | 79        |
| 2.19.4.   | <i>Convert measurements from ISO to ANSI (and vice versa)</i> .....  | 79        |
| 2.20.     | DRAWING LIMITS .....   | 81        |
| 2.21.     | GRID (  ) AND SNAP (  ) COMMANDS ..... | 83        |
| 2.21.1.   | <i>Toggle Grid and Snap in the model space</i> .....   | 84        |
| 2.21.2.   | <i>Toggle the Grid and Snap in the layout</i> .....  | 86        |
| 2.21.3.   | <i>Grid properties</i> .....   | 86        |
| 2.21.3.1. | Grid style .....   | 86        |
| 2.21.3.2. | Grid spacing.....  | 86        |
| 2.21.3.3. | Grid behavior.....   | 87        |
| 2.21.3.4. | Grid color.....  | 88        |
| 2.21.4.   | <i>Snap properties</i> .....   | 88        |
| 2.21.4.1. | Snap spacing .....   | 88        |
| 2.21.4.2. | Polar spacing.....   | 88        |
| 2.21.4.3. | Snap type .....  | 88        |
| 2.22.     | SAVE A FILE .....  | 90        |
| 2.22.1.   | <i>Save As</i>  .....   | 90        |
| 2.22.2.   | <i>Save</i>  .....  | 91        |
| 2.23.     | OPEN A PRE-EXISTING FILE  .....   | 92        |
| 2.24.     | CLOSE A FILE.....  | 94        |
| 2.25.     | EXIT AUTOCAD .....   | 95        |
| 3.        | <b>BASICS OF 2-DIMENSIONAL DRAWINGS.....</b>   | <b>97</b> |
| 3.1.      | LEARNING OBJECTIVES .....  | 97        |
| 3.2.      | INTRODUCTION .....   | 98        |
| 3.3.      | DYNAMIC INPUT  .....  | 98        |

|           |   |     |
|-----------|---|-----|
| 3.3.1.    | <i>Toggle dynamic input</i> .....   | 99  |
| 3.3.2.    | <i>Components of a dynamic input</i> .....  | 99  |
| 3.3.2.1.  | Pointer input.....  | 100 |
| 3.3.2.2.  | Dimension input.....  | 101 |
| 3.3.2.3.  | Dynamic prompts.....  | 103 |
| 3.3.3.    | <i>Drafting tooltip appearance</i> .....  | 104 |
| 3.4.      | INPUT DATA .....  | 105 |
| 3.4.1.1.  | Tab key .....   | 105 |
| 3.4.1.2.  | Comma key .....   | 106 |
| 3.4.1.3.  | Less than key.....  | 107 |
| 3.4.1.4.  | Remove typing errors from the dynamic input tooltips.....   | 107 |
| 3.5.      | REFERENCE SYSTEM .....  | 107 |
| 3.5.1.    | <i>Cartesian coordinates</i> .....  | 108 |
| 3.5.2.    | <i>Polar coordinates</i> .....  | 108 |
| 3.5.3.    | <i>AutoCAD and the coordinate systems</i> .....   | 109 |
| 3.5.3.1.  | Absolute Cartesian coordinates.....   | 109 |
| 3.5.3.2.  | Relative Cartesian coordinates.....   | 110 |
| 3.5.3.3.  | Absolute Polar coordinates.....   | 111 |
| 3.5.3.4.  | Relative Polar coordinates.....   | 112 |
| 3.6.      | POINT  .....                       | 112 |
| 3.6.1.    | <i>Change style and size of a point</i> .....   | 113 |
| 3.6.1.1.  | Style .....   | 114 |
| 3.6.1.2.  | Point size.....   | 114 |
| 3.7.      | LINE  .....                        | 114 |
| 3.7.1.    | <i>Points selection</i> .....   | 115 |
| 3.7.2.    | <i>Snap points</i> .....  | 116 |
| 3.7.3.    | <i>Cartesian coordinates</i> .....  | 117 |
| 3.7.4.    | <i>Polar coordinates</i> .....  | 117 |
| 3.7.5.    | <i>Orthogonal command</i>  ..... | 118 |
| 3.8.      | CIRCLE  .....                    | 120 |
| 3.9.      | POLYGON  .....                   | 130 |
| 3.10.     | POLYLINE  .....                  | 133 |
| 3.11.     | ELLIPSE  .....                   | 139 |
| 3.12.     | ELLIPTICAL ARC  .....            | 145 |
| 3.13.     | CIRCULAR ARC  .....              | 145 |
| 3.14.     | RECTANGLE  .....                 | 145 |
| 3.15.     | OBJECT APPEARANCE .....   | 150 |
| 3.15.1.   | <i>Color Control</i> .....  | 151 |
| 3.15.1.1. | Set color of an object before it is drawn.....  | 151 |
| 3.15.1.2. | Change color of an object after it is drawn.....  | 153 |
| 3.15.2.   | <i>Lineweight Control</i> .....   | 153 |
| 3.15.2.1. | Change thickness of a line before it is drawn.....  | 153 |
| 3.15.2.2. | Change thickness of a line after it is drawn.....   | 154 |
| 3.15.3.   | <i>Linetype Control</i> .....   | 155 |
| 3.15.3.1. | Load a linetype.....  | 155 |
| 3.15.3.2. | Change linetype before an object is drawn.....  | 157 |
| 3.15.3.3. | Change linetype after an object is drawn.....   | 158 |
| 3.15.3.4. | Linetype scale .....  | 158 |
| 3.16.     | TEXT  .....                      | 160 |
| 3.16.1.   | <i>Create multiline text</i> .....  | 160 |
| 3.16.2.   | <i>Text Editor</i> .....  | 161 |
| 3.16.2.1. | Style .....   | 162 |

|             |  |            |
|-------------|--|------------|
| 3.16.2.1.1. | Font height .....                                  | 162        |
| 3.16.2.1.2. | Background mask.....                               | 163        |
| 3.16.2.2.   | Formatting.....                                    | 164        |
| 3.16.2.2.1. | Stacked characters.....                            | 165        |
| 3.16.2.3.   | Paragraph .....                                    | 165        |
| 3.16.2.3.1. | Justification .....                                | 166        |
| 3.16.2.3.2. | List .....   | 167        |
| 3.16.2.3.3. | Line spacing.....                                  | 167        |
| 3.16.2.3.4. | Paragraph dialog box.....                          | 168        |
| 3.16.2.4.   | Insert .....                                       | 169        |
| 3.16.2.4.1. | Column.....  | 169        |
| 3.16.2.4.2. | Symbol.....  | 169        |
| 3.16.2.5.   | Spell check.....                                   | 170        |
| 3.16.2.6.   | Tools .....  | 171        |
| 3.16.2.7.   | Options.....                                       | 172        |
| 3.16.2.8.   | Close .....  | 172        |
| 3.16.3.     | <i>Annotate tab and Text panel</i> .....           | 172        |
| 3.16.4.     | <i>Express Tools tab and Text panel</i> .....      | 173        |
| 3.16.4.1.1. | Arc Aligned.....                                   | 174        |
| 3.16.4.1.2. | Enclose in object .....                            | 175        |
| 3.17.       | HATCH .....  | 177        |
| 3.17.1.     | <i>Hatch creation tab</i> .....                    | 178        |
| 3.17.1.1.1. | Boundaries .....                                   | 178        |
| 3.17.1.1.2. | Pattern .....                                      | 179        |
| 3.17.1.1.3. | Properties .....                                   | 179        |
| 3.17.1.1.4. | Options.....                                       | 180        |
| 3.17.1.1.5. | origin.....  | 182        |
| 3.17.1.1.6. | Close .....  | 182        |
| 3.17.2.     | Hatch an area .....                                | 182        |
| 3.18.       | TABLE .....  | 185        |
| 3.18.1.     | <i>Create a table.....</i>                         | 186        |
| 3.18.2.     | <i>Table resize .....</i>                          | 187        |
| 3.18.3.     | <i>Modify table's shape .....</i>                  | 189        |
| 3.18.4.     | <i>The cursor movement .....</i>                   | 192        |
| 3.18.5.     | <i>Insert a multiline text in a cell.....</i>      | 192        |
| 3.18.6.     | <i>The data type.....</i>                          | 192        |
| 3.18.7.     | <i>Populate the table .....</i>                    | 194        |
| 3.18.8.     | <i>Modify the contents of a table .....</i>        | 195        |
| 3.18.8.1.   | Table Style dialog box  .....                      | 195        |
| 3.18.8.2.   | Table update using the property palette .....      | 201        |
| 4.          | <b>BASICS OF 2-DIMENSIONAL EDITING.....</b>        | <b>205</b> |
| 4.1.        | LEARNING OBJECTIVES .....                          | 205        |
| 4.2.        | INTRODUCTION .....                                 | 206        |
| 4.3.        | GRIPS.....   | 206        |
| 4.3.1.      | <i>Grips toggle .....</i>                          | 206        |
| 4.3.2.      | <i>Change the size and color of the grips.....</i> | 206        |
| 4.4.        | OBJECT SELECTION .....                             | 208        |
| 4.4.1.      | <i>Method #1: Green Method.....</i>                | 208        |
| 4.4.1.1.    | Version #1.....                                    | 208        |
| 4.4.1.2.    | Version #2.....                                    | 208        |
| 4.4.2.      | <i>Method #2: Blue Method .....</i>                | 209        |
| 4.4.2.1.    | Version #1.....                                    | 209        |
| 4.4.2.2.    | Version #2.....                                    | 209        |
| 4.4.3.      | <i>Method #3 .....</i>                             | 209        |
| 4.5.        | OBJECT DE-SELECTION.....                           | 210        |
| 4.6.        | ZOOM CAPABILITIES.....                             | 210        |

|           |  |   |     |
|-----------|--|---|-----|
| 4.6.1.    | Zoom window                              |    | 211 |
| 4.6.2.    | Zoom scale                               |    | 212 |
| 4.6.3.    | Zoom center                              |    | 213 |
| 4.6.4.    | Zoom object                              |    | 213 |
| 4.6.5.    | Zoom in                                  |    | 213 |
| 4.6.6.    | Zoom out                                 |    | 213 |
| 4.6.7.    | Zoom all                                 |    | 214 |
| 4.6.8.    | Zoom-wheel                               |   | 214 |
| 4.7.      | PAN                                      |    | 214 |
| 4.8.      | DRAW ORDER                               |    | 215 |
| 4.8.1.    | Bring to front                           |    | 216 |
| 4.8.2.    | Send to back                             |    | 216 |
| 4.9.      | OBJECT SNAP                              |    | 216 |
| 4.9.1.    | Toggle object snap                       |   | 217 |
| 4.9.2.    | Size and color of the object snap cursor |   | 218 |
| 4.9.3.    | Object snap commands                     |   | 218 |
| 4.9.3.1.  | Endpoint                                 |    | 219 |
| 4.9.3.2.  | Midpoint                                 |    | 219 |
| 4.9.3.3.  | Node                                     |   | 220 |
| 4.9.3.4.  | Intersection                             |  | 220 |
| 4.9.3.5.  | Extension                                |  | 221 |
| 4.9.3.6.  | Apparent intersection                    |  | 222 |
| 4.9.3.7.  | Center                                   |  | 223 |
| 4.9.3.8.  | Quadrant                                 |  | 223 |
| 4.9.3.9.  | Geometric center                         |  | 223 |
| 4.9.3.10. | Tangent                                  |  | 224 |
| 4.9.3.11. | Perpendicular                            |  | 225 |
| 4.10.     | THE EDITING COMMANDS                     |   | 226 |
| 4.11.     | CANCEL                                   |   | 227 |
| 4.12.     | ERASE                                    |  | 227 |
| 4.12.1.   | Erase one object                         |   | 228 |
| 4.12.1.1. | Using delete key                         |   | 228 |
| 4.12.1.2. | Using Erase tool                         |   | 228 |
| 4.12.2.   | Erase multiple object simultaneously     |   | 228 |
| 4.13.     | UNDO                                     |  | 228 |
| 4.13.1.   | Undo one command                         |   | 229 |
| 4.13.2.   | Undo several commands                    |   | 229 |
| 4.14.     | REDO                                     |  | 229 |
| 4.14.1.   | Redo one command                         |   | 230 |
| 4.14.2.   | Redo several commands                    |   | 230 |
| 4.15.     | OOPS                                     |   | 230 |
| 4.16.     | DELETE DUPLICATE OBJECTS                 |  | 231 |

|           |   |            |
|-----------|---|------------|
| 4.17.     | COPY   | 232        |
| 4.18.     | ARRAY .....   | 235        |
| 4.18.1.   | <i>Rectangular Array</i>                     | 236        |
| 4.18.1.1. | Rectangular array's grip points .....   | 240        |
| 4.18.2.   | <i>Polar array</i>                           | 242        |
| 4.18.2.1. | Fill angle .....  | 245        |
| 4.18.2.2. | Angle between .....   | 246        |
| 4.18.2.3. | Polar array and grip points .....   | 246        |
| 4.18.3.   | <i>Path array</i>                            | 247        |
| 4.18.3.1. | Path array and grip points .....  | 251        |
| 4.18.4.   | <i>Edit array</i> .....   | 251        |
| 4.19.     | MIRROR                                       | 252        |
| 4.20.     | OFFSET                                       | 254        |
| 4.21.     | MOVE   | 257        |
| 4.21.1.   | <i>Move in xy-plane</i> .....   | 259        |
| 4.21.2.   | <i>Move in z-direction</i> .....  | 259        |
| 4.22.     | ROTATE                                       | 260        |
| 4.23.     | SCALE                                        | 262        |
| 4.24.     | STRETCH                                      | 264        |
| 4.25.     | BREAK                                        | 266        |
| 4.26.     | BREAK AT A POINT                           | 268        |
| 4.27.     | EXPLODE                                    | 268        |
| 4.28.     | JOIN                                       | 269        |
| 4.28.1.1. | Lines .....   | 271        |
| 4.28.1.2. | Circular arc .....  | 271        |
| 4.28.1.3. | Polyline .....  | 273        |
| 4.28.1.4. | Spline .....  | 273        |
| 4.28.1.5. | Combination of objects .....  | 273        |
| 4.29.     | FILLET                                     | 273        |
| 4.30.     | CHAMFER                                    | 276        |
| 4.31.     | TRIM                                       | 280        |
| 4.31.1.   | <i>Trim: FAQ</i> .....  | 282        |
| 4.32.     | EXTEND                                     | 283        |
| 4.33.     | POLYLINE EDIT                              | 285        |
| 4.34.     | GRIPS AND OBJECT EDITING .....  | 290        |
| 4.34.1.   | <i>Select a point</i> .....   | 291        |
| 4.34.2.   | <i>Stretch/shrink</i> .....   | 291        |
| 4.34.3.   | <i>Erase</i> .....  | 291        |
| 4.34.4.   | <i>Move</i> .....   | 292        |
| 4.34.5.   | <i>Scale</i> .....  | 292        |
| 4.34.6.   | <i>Rotate</i> .....   | 292        |
| 4.35.     | THE PROPERTIES PALETTE AND OBJECT EDITING  | 293        |
| <b>5.</b> | <b>LAYERS .....</b>   | <b>297</b> |
| 5.1.      | LEARNING OBJECTIVES .....   | 297        |

|           |  |            |
|-----------|--|------------|
| 5.2.      | INTRODUCTION.....  | 298        |
| 5.3.      | LAYERS IN AUTOCAD .....  | 299        |
| 5.4.      |  LAYER COMMAND .....                | 300        |
| 5.5.      | LAYER PROPERTIES MANAGER .....   | 301        |
| 5.5.1.    | <i>Characteristics of a layer</i> .....  | 301        |
| 5.5.2.    |  Create a new layer .....           | 305        |
| 5.5.3.    |  Delete an existing layer .....     | 306        |
| 5.5.4.    |  Make a layer a current layer ..... | 306        |
| 5.6.      | DRAWING AND LAYERS.....  | 307        |
| 5.7.      | THE DEFPOINTS LAYER .....  | 307        |
| 5.8.      | MOVE OBJECTS BETWEEN LAYERS .....  | 307        |
| 5.9.      | UPDATE LAYER PROPERTIES .....  | 308        |
| 5.10.     | LAYERS: FAQ .....  | 309        |
| 5.11.     | ILLUSTRATIVE EXAMPLE.....  | 310        |
| <b>6.</b> | <b>BLOCKS.....</b>   | <b>313</b> |
| 6.1.      | LEARNING OBJECTIVES .....  | 313        |
| 6.2.      | INTRODUCTION.....  | 314        |
| 6.3.      |  BASIC BLOCK.....                   | 314        |
| 6.3.1.    | <i>Create a basic block</i>  .....  | 315        |
| 6.3.2.    | <i>Block definition dialog box</i> .....   | 315        |
| 6.4.      | WBLOCK .....   | 318        |
| 6.4.1.    | <i>Create a Wblock</i> .....   | 318        |
| 6.4.2.    | <i>Write block dialog box</i> .....  | 318        |
| 6.5.      |  BLOCK WITH ATTRIBUTES .....      | 320        |
| 6.5.1.    | <i>The initial setup</i> .....   | 320        |
| 6.5.2.    | <i>Attribute definition dialog box</i> .....   | 321        |
| 6.5.3.    | <i>Create attributes</i> .....   | 323        |
| 6.5.4.    | <i>Create block with attributes</i> .....  | 324        |
| 6.5.5.    | <i>Convert to Wblock</i> .....   | 325        |
| 6.6.      | BLOCK WITH TEXT BOXES .....  | 325        |
| 6.7.      |  BASIC BLOCK INSERTION .....      | 326        |
| 6.7.1.    | <i>Insert dialog box</i> .....   | 327        |
| 6.7.2.    | <i>Insert a block with default values</i> .....  | 328        |
| 6.7.3.    | <i>Change the scale of the block at the insertion</i> .....  | 329        |
| 6.7.4.    | <i>Rotate the block at the insertion</i> .....   | 331        |
| 6.7.5.    | <i>Insert a Wblock</i> .....   | 332        |
| 6.7.6.    | <i>Insert a block with attributes</i> .....  | 332        |
| 6.7.7.    | <i>Insert a block with text boxes</i> .....  | 333        |
| 6.8.      | COMBINE BLOCKS .....   | 333        |
| 6.9.      | MODIFY BLOCK.....  | 334        |
| 6.10.     |  DESIGN CENTER .....              | 334        |
| 6.10.1.   | <i>Insert a block (known dimension)</i> .....  | 337        |
| 6.10.2.   | <i>Insert a block (unknown dimension)</i> .....  | 338        |
| <b>7.</b> | <b>LAYOUTS AND TEMPLATE FILES .....</b>  | <b>339</b> |
| 7.1.      | LEARNING OBJECTIVES .....  | 339        |
| 7.2.      | INTRODUCTION.....  | 340        |
| 7.3.      | LAYOUT .....   | 340        |
| 7.3.1.    | <i>Paper background and shadow</i> .....   | 341        |
| 7.3.2.    | <i>Printable area</i> .....  | 341        |

|           |   |            |
|-----------|---|------------|
| 7.3.3.    | <i>Viewport</i> .....   | 346        |
| 7.3.3.1.  | Viewport resizing.....  | 346        |
| 7.3.3.2.  | Multiple viewports.....   | 346        |
| 7.3.3.3.  | Non-rectangular viewports.....  | 348        |
| 7.3.3.4.  | Viewport scaling.....   | 350        |
| 7.3.3.5.  | Rescale a viewport.....   | 350        |
| 7.3.3.6.  | Lock the scale of a viewport .....  | 351        |
| 7.4.      | ADD AN ENTRY IN THE SCALE LIST.....   | 353        |
| 7.5.      | LAYOUT MANIPULATION.....  | 354        |
| 7.5.1.    | <i>Delete a layout</i> .....  | 355        |
| 7.5.2.    | <i>Move a layout</i> .....  | 356        |
| 7.5.3.    | <i>Copy a layout</i> .....  | 357        |
| 7.5.4.    | <i>Rename a layout</i> .....  | 357        |
| 7.5.5.    | <i>Insert a layout</i> .....  | 358        |
| 7.5.5.1.  | Default layout .....  | 358        |
| 7.5.5.2.  | Layout from template.....   | 358        |
| 7.5.6.    | <i>Grid and Snap commands</i> .....   | 359        |
| 7.6.      | LAYERS FREEZING AND LAYOUTS.....  | 359        |
| 7.7.      | OBJECT APPEARANCE AND LAYOUTS.....  | 362        |
| 7.8.      | TEMPLATE FILE .....   | 363        |
| 7.8.1.    | <i>Landscape template for ISO units</i> .....   | 364        |
| 7.8.2.    | <i>Portrait template for ISO units</i> .....  | 368        |
| 7.8.3.    | <i>Template for ANSI units</i> .....  | 369        |
| 7.9.      | MODIFY ATTRIBUTE OF A BLOCK IN A TEMPLATE FILE.....   | 371        |
| <b>8.</b> | <b>DIMENSIONING TECHNIQUES.....</b>   | <b>373</b> |
| 8.1.      | LEARNING OBJECTIVES .....   | 373        |
| 8.2.      | INTRODUCTION .....  | 374        |
| 8.3.      | DIMENSIONING IN GENERAL.....  | 374        |
| 8.4.      | TERMINOLOGY .....   | 375        |
| 8.5.      | IMPORTANT POINTS TO REMEMBER.....   | 376        |
| 8.6.      | DIMENSION STYLES  .....          | 377        |
| 8.7.      | MODIFY DIMENSION STYLE DIALOG BOX.....  | 378        |
| 8.7.1.    | <i>Lines</i> .....  | 379        |
| 8.7.2.    | <i>Symbols and arrows</i> .....   | 380        |
| 8.7.3.    | <i>Text</i> .....   | 381        |
| 8.7.4.    | <i>Fit</i> .....  | 382        |
| 8.7.5.    | <i>Primary units</i> .....  | 382        |
| 8.7.6.    | <i>Alternate units</i> .....  | 383        |
| 8.7.7.    | <i>Tolerance</i> .....  | 383        |
| 8.8.      | MODIFY DIMENSION STYLE.....   | 383        |
| 8.8.1.    | <i>Modify dimension style using the dialog box</i> .....  | 383        |
| 8.8.2.    | <i>Modify dimension style using the properties palette</i> .....  | 383        |
| 8.9.      | DIMENSIONING TECHNIQUES  .....   | 385        |
| 8.9.1.    | <i>Linear dimensions</i>  .....  | 385        |
| 8.9.1.1.  | Extension lines.....  | 385        |
| 8.9.1.2.  | Object selection.....   | 386        |
| 8.9.1.3.  | Text relocation .....   | 387        |
| 8.9.1.4.  | Space adjustment  .....          | 388        |
| 8.9.2.    | <i>Aligned dimensions</i>  ..... | 390        |
| 8.9.3.    | <i>Angular dimensions</i>  ..... | 390        |
| 8.9.3.1.  | Angles < 180° .....   | 391        |
| 8.9.3.2.  | Angles > 180° .....   | 392        |

|   |   |            |
|---|---|------------|
| 8.9.4. Dimensioning radii                                   |  | 393        |
| 8.9.5. Dimensioning circles                                 |  | 394        |
| 8.10. CENTER MARK   |  | 396        |
| 8.10.1. Command line method                                 |   | 396        |
| 8.10.2. Panel method  |  | 398        |
| 8.11. LEADER LINES  |  | 398        |
| 8.11.1. Arrow   |   | 400        |
| 8.11.2. Arrowhead size                                      |   | 400        |
| 8.12. SMART DIMENSIONS                                      |  | 401        |
| 8.13. TYPES OF DIMENSIONS                                   |   | 404        |
| 8.13.1. Continue dimension                                  |  | 404        |
| 8.13.2. Baseline dimensions                                 |  | 405        |
| 8.13.3. Ordinate dimensions                                 |  | 407        |
| 8.13.4. Tabular dimensions                                  |   | 409        |
| 8.13.5. Combined dimensions                                 |  | 409        |
| 8.14. QUICK DIMENSIONS                                      |  | 409        |
| 8.15. DIMENSIONING FILLETS AND ROUNDS                       |   | 410        |
| 8.16. CENTERLINE  |   | 411        |
| 8.17. LINE OF SYMMETRY                                      |   | 411        |
| <b>9. TOLERANCE</b>   |   | <b>413</b> |
| 9.1. LEARNING OBJECTIVES                                    |   | 413        |
| 9.2. INTRODUCTION   |   | 414        |
| 9.3. TERMINOLOGY  |   | 415        |
| 9.4. TOLERANCE METHODS                                      |   | 415        |
| 9.4.1. Plus-minus method                                    |   | 415        |
| 9.4.1.1. Unilateral   |   | 416        |
| 9.4.1.2. Bilateral  |   | 416        |
| 9.4.1.3. Tolerance expression                               |   | 416        |
| 9.4.1.4. Unilateral values                                  |   | 416        |
| 9.4.1.5. Bilateral values                                   |   | 417        |
| 9.4.1.6. Usage of Plus-minus tolerance                      |   | 418        |
| 9.4.2. Limits tolerance                                     |   | 418        |
| 9.5. STANDARD TOLERANCE                                     |   | 418        |
| 9.6. DOUBLE DIMENSIONING                                    |   | 419        |
| 9.6.1. Double dimensioning: an error                        |   | 419        |
| 9.6.2. Solution #1  |   | 420        |
| 9.6.3. Solution #2  |   | 420        |
| 9.7. CHAIN AND BASELINE DIMENSION                           |   | 420        |
| 9.8. TOLERANCE STUDY  |   | 421        |
| 9.9. TOLERANCE IN AUTOCAD                                   |   | 422        |
| 9.9.1. Tolerance tab  |   | 423        |
| 9.9.1.1. Tolerance format                                   |   | 423        |
| 9.9.1.2. Tolerance Alignment                                |   | 425        |
| 9.9.1.3. Zero Suppression                                   |   | 425        |
| 9.9.2. Add or modify tolerance                              |   | 426        |
| 9.9.2.1. Add or modify tolerance using the dialog box       |   | 426        |
| 9.9.2.2. Add or modify tolerance using the property palette |   | 426        |
| <b>10. LAND SURVEY</b>                                      |   | <b>429</b> |

|            |  |     |
|------------|--|-----|
| 10.1.      | LEARNING OBJECTIVES .....                            | 429 |
| 10.2.      | INTRODUCTION .....                                   | 430 |
| 10.3.      | LOCATION .....                                       | 430 |
| 10.3.1.    | <i>Longitudes</i> .....                              | 430 |
| 10.3.2.    | <i>Latitudes</i> .....                               | 430 |
| 10.3.3.    | <i>Location on a map</i> .....                       | 431 |
| 10.4.      | ANGULAR MEASUREMENT .....                            | 431 |
| 10.4.1.    | <i>Units of measurement</i> .....                    | 432 |
| 10.4.2.    | <i>Direction</i> .....                               | 432 |
| 10.4.2.1.  | Azimuth .....  | 432 |
| 10.4.2.2.  | Bearing.....   | 432 |
| 10.4.2.3.  | Relationship between azimuth and bearing.....        | 432 |
| 10.5.      | TRAVERSE .....                                       | 433 |
| 10.5.1.    | <i>Open traverse</i> .....                           | 433 |
| 10.5.2.    | <i>Closed traverse</i> .....                         | 434 |
| 10.5.2.1.  | Connecting traverse .....                            | 434 |
| 10.5.2.2.  | Loop traverse .....                                  | 434 |
| 10.6.      | DRAWING A TRAVERSE USING AUTOCAD .....               | 435 |
| 10.6.1.    | <i>Traverse for the given azimuths</i> .....         | 435 |
| 10.6.2.    | <i>Traverse for the given bearings</i> .....         | 437 |
| 10.7.      | ADD DIMENSIONS TO A TRAVERSE .....                   | 439 |
| 10.7.1.    | <i>Length</i> .....                                  | 439 |
| 10.7.2.    | <i>Add reference line to a traverse</i> .....        | 440 |
| 10.7.3.    | <i>Azimuth angle</i> .....                           | 441 |
| 10.7.4.    | <i>Bearing angle</i> .....                           | 441 |
| 10.7.5.    | <i>Save the file</i> .....                           | 441 |
| 10.8.      | PARCEL.....  | 441 |
| 10.9.      | DEED .....   | 441 |
| 10.10.     | LAND SURVEY .....                                    | 442 |
| 10.11.     | RECTANGULAR SYSTEM .....                             | 442 |
| 10.11.1.   | <i>Reference lines</i> .....                         | 442 |
| 10.11.2.   | <i>Township and range</i> .....                      | 443 |
| 10.12.     | METES AND BOUNDS .....                               | 445 |
| 10.12.1.   | <i>Land description using metes and bounds</i> ..... | 446 |
| 10.12.2.   | <i>AutoCAD and Metes and Bounds</i> .....            | 447 |
| 10.13.     | LOTS AND BLOCKS .....                                | 449 |
| 10.13.1.   | <i>Terminology</i> .....                             | 449 |
| 10.13.2.   | <i>Lots and Blocks</i> .....                         | 449 |
| 10.13.3.   | <i>AutoCAD and Lot and Block</i> .....               | 450 |
| 10.13.4.   | <i>Area of a lot</i> .....                           | 457 |
| 10.13.4.1. | Closed boundary method .....                         | 457 |
| 10.13.4.2. | Hatch method.....                                    | 458 |
| 10.13.4.3. | Area command method .....                            | 459 |
| 11.        | CONTOURS.....  | 463 |
| 11.1.      | LEARNING OBJECTIVES .....                            | 463 |
| 11.2.      | INTRODUCTION .....                                   | 464 |
| 11.3.      | CHARACTERISTICS OF A CONTOUR LINE .....              | 465 |
| 11.4.      | TERMINOLOGY .....                                    | 465 |
| 11.5.      | AUTOCAD AND CONTOUR MAP .....                        | 469 |
| 11.5.1.    | <i>Create Script file</i> .....                      | 470 |
| 11.5.2.    | <i>Create layers</i> .....                           | 470 |
| 11.5.3.    | <i>Change point style</i> .....                      | 470 |
| 11.5.4.    | <i>Read the script files</i> .....                   | 470 |
| 11.5.5.    | <i>Create the contour map</i> .....                  | 472 |
| 11.5.6.    | <i>Curve fitting</i> .....                           | 473 |

|                                 |  |     |
|---------------------------------|--|-----|
| 11.5.7.                         | <i>Add the labels to the index contours.....</i> | 473 |
| <b>12. DRAINAGE BASIN .....</b> | <b>475</b>                                       |     |
| 12.1.                           | LEARNING OBJECTIVES .....                        | 475 |
| 12.2.                           | INTRODUCTION.....                                | 476 |
| 12.3.                           | HYDROLOGIC CYCLE .....                           | 476 |
| 12.4.                           | TERMINOLOGY .....                                | 476 |
| 12.5.                           | WATERSHED OR DRAINAGE BASIN .....                | 478 |
| 12.6.                           | WATERSHED CHARACTERISTICS.....                   | 479 |
| 12.6.1.                         | <i>Drainage area.....</i>                        | 479 |
| 12.6.2.                         | <i>Watershed length.....</i>                     | 479 |
| 12.6.3.                         | <i>Watershed slope.....</i>                      | 479 |
| 12.6.4.                         | <i>Miscellaneous .....</i>                       | 479 |
| 12.7.                           | MAJOR STEPS IN A WATERSHED DELINEATION.....      | 480 |
| 12.8.                           | WATERSHED DELINEATION USING AUTOCAD .....        | 480 |
| <b>13. FLOODPLAINS.....</b>     | <b>491</b>                                       |     |
| 13.1.                           | LEARNING OBJECTIVES .....                        | 491 |
| 13.2.                           | INTRODUCTION.....                                | 492 |
| 13.3.                           | TERMINOLOGY .....                                | 492 |
| 13.4.                           | MAJOR STEPS IN A FLOODPLAIN DELINEATION .....    | 494 |
| 13.5.                           | FLOODPLAIN DELINEATION USING AUTOCAD .....       | 495 |
| <b>14. ROAD DESIGN .....</b>    | <b>511</b>                                       |     |
| 14.1.                           | LEARNING OBJECTIVES .....                        | 511 |
| 14.2.                           | INTRODUCTION.....                                | 512 |
| 14.3.                           | PLAN AND PROFILE.....                            | 512 |
| 14.3.1.                         | <i>Plan.....</i>                                 | 512 |
| 14.3.2.                         | <i>Profile .....</i>                             | 513 |
| 14.4.                           | DRAW ROAD PLAN USING AUTOCAD .....               | 513 |
| 14.5.                           | PLOT THE PROFILE USING AUTOCAD .....             | 516 |
| 14.6.                           | CROSS-SECTION .....                              | 522 |
| 14.7.                           | DRAW THE CROSS-SECTION USING AUTOCAD .....       | 522 |
| <b>15. EARTHWORK .....</b>      | <b>531</b>                                       |     |
| 15.1.                           | LEARNING OBJECTIVES .....                        | 531 |
| 15.2.                           | INTRODUCTION.....                                | 532 |
| 15.3.                           | EARTHWORK .....                                  | 532 |
| 15.3.1.                         | <i>Cut .....</i>                                 | 532 |
| 15.3.2.                         | <i>Fill .....</i>                                | 532 |
| 15.3.3.                         | <i>Location of a road .....</i>                  | 532 |
| 15.4.                           | SLOPE.....                                       | 532 |
| 15.5.                           | ANGLE OF REPOSE .....                            | 533 |
| 15.6.                           | PLAN AND EXISTING PROFILE OF A ROAD .....        | 534 |
| 15.7.                           | PROPOSED PROFILE OF A ROAD.....                  | 534 |
| 15.8.                           | DELINEATE THE EARTHWORK USING AUTOCAD .....      | 536 |
| <b>16. FLOOR PLAN .....</b>     | <b>543</b>                                       |     |
| 16.1.                           | LEARNING OBJECTIVES .....                        | 543 |
| 16.2.                           | INTRODUCTION.....                                | 544 |
| 16.3.                           | FLOOR PLAN .....                                 | 546 |
| 16.4.                           | WINDOWS .....                                    | 546 |
| 16.4.1.                         | <i>Types of windows.....</i>                     | 547 |
| 16.4.2.                         | <i>Window sizes.....</i>                         | 547 |
| 16.4.3.                         | <i>Window selection .....</i>                    | 548 |

|             |   |            |
|-------------|---|------------|
| 16.5.       | DOORS.....                                    | 548        |
| 16.5.1.     | <i>Types of Door.....</i>                     | 549        |
| 16.5.2.     | <i>Door sizes.....</i>                        | 551        |
| 16.5.3.     | <i>Door selection.....</i>                    | 551        |
| 16.5.4.     | <i>Door appearance in floor plan .....</i>    | 551        |
| 16.6.       | WALL .....                                    | 552        |
| 16.6.1.     | <i>Exterior .....</i>                         | 552        |
| 16.6.2.     | <i>Interior .....</i>                         | 552        |
| 16.6.3.     | <i>Non-load bearing .....</i>                 | 552        |
| 16.6.4.     | <i>Load bearing.....</i>                      | 552        |
| 16.6.5.     | <i>Wall thickness .....</i>                   | 553        |
| 16.7.       | STAIR.....                                    | 553        |
| 16.7.1.     | <i>Terminology .....</i>                      | 553        |
| 16.7.2.     | <i>Important points to remember.....</i>      | 554        |
| 16.7.3.     | <i>Types of stairs .....</i>                  | 555        |
| 16.8.       | BASICS OF FLOOR PLAN DESIGN.....              | 555        |
| 16.9.       | DESIGN TECHNIQUE .....                        | 557        |
| 16.10.      | AUTOCAD AND FLOOR PLAN.....                   | 557        |
| 16.10.1.    | <i>New file .....</i>                         | 558        |
| 16.10.2.    | <i>The input units.....</i>                   | 558        |
| 16.10.2.1.  | <i>Architectural .....</i>                    | 558        |
| 16.10.2.2.  | <i>Precision .....</i>                        | 558        |
| 16.10.3.    | <i>Load linetypes .....</i>                   | 558        |
| 16.10.4.    | <i>Orthogonal lines .....</i>                 | 559        |
| 16.10.5.    | <i>Layers.....</i>                            | 559        |
| 16.10.6.    | <i>The floor plan.....</i>                    | 559        |
| 16.10.6.1.  | <i>Exterior wall .....</i>                    | 559        |
| 16.10.6.2.  | <i>Interior walls.....</i>                    | 561        |
| 16.10.6.3.  | <i>Label .....</i>                            | 561        |
| 16.10.6.4.  | <i>Doors .....</i>                            | 563        |
| 16.10.6.5.  | <i>Walls cleanup.....</i>                     | 568        |
| 16.10.6.6.  | <i>Windows .....</i>                          | 568        |
| 16.10.6.7.  | <i>Roofline .....</i>                         | 571        |
| 16.10.6.8.  | <i>Wall hatch.....</i>                        | 571        |
| 16.10.6.9.  | <i>Porch.....</i>                             | 571        |
| 16.10.6.10. | <i>Kitchen .....</i>                          | 573        |
| 16.10.6.11. | <i>Master bathroom.....</i>                   | 576        |
| 16.10.6.12. | <i>North direction.....</i>                   | 578        |
| 16.10.6.13. | <i>The complete plan .....</i>                | 579        |
| 16.11.      | DIMENSIONING AN ARCHITECTURAL DRAWING.....    | 579        |
| 16.11.1.    | <i>Create Layers.....</i>                     | 580        |
| 16.11.2.    | <i>Set Dimension Style dialog box.....</i>    | 580        |
| 16.11.3.    | <i>Add dimensions to the floor plan .....</i> | 582        |
| <b>17.</b>  | <b>ELEVATIONS .....</b>                       | <b>591</b> |
| 17.1.       | LEARNING OBJECTIVES .....                     | 591        |
| 17.2.       | INTRODUCTION .....                            | 592        |
| 17.3.       | ROOF .....                                    | 594        |
| 17.3.1.     | <i>Terminology .....</i>                      | 594        |
| 17.3.2.     | <i>Types of roof .....</i>                    | 594        |
| 17.3.3.     | <i>Important points.....</i>                  | 594        |
| 17.4.       | AUTOCAD AND ROOF PLAN.....                    | 595        |
| 17.4.1.     | <i>Open file.....</i>                         | 595        |
| 17.4.2.     | <i>Load linetypes .....</i>                   | 595        |
| 17.4.3.     | <i>Layers.....</i>                            | 595        |
| 17.4.4.     | <i>The roof plan.....</i>                     | 596        |
| 17.5.       | AUTOCAD AND THE FRONT ELEVATION .....         | 599        |

|            |  |            |
|------------|--|------------|
| 17.5.1.    | <i>Open file</i> .....                   | 599        |
| 17.5.2.    | <i>Load linetypes</i> .....              | 599        |
| 17.5.3.    | <i>Orthogonal lines</i> .....            | 599        |
| 17.5.4.    | <i>Layers</i> .....                      | 600        |
| 17.5.5.    | <i>The front elevation</i> .....         | 600        |
| 17.5.5.1.  | Ground level.....                        | 600        |
| 17.5.5.2.  | Slab level.....                          | 601        |
| 17.5.5.3.  | Doors.....                               | 602        |
| 17.5.5.4.  | Windows .....                            | 604        |
| 17.5.5.5.  | Front wall .....                         | 609        |
| 17.5.5.6.  | Roof .....                               | 611        |
| 17.5.5.7.  | Front porch.....                         | 614        |
| 17.5.5.8.  | Landscaping .....                        | 616        |
| 17.5.5.9.  | Template file .....                      | 617        |
| 17.6.      | AUTOCAD AND THE LEFT SIDE ELEVATION..... | 617        |
| 17.6.1.    | <i>Open file</i> .....                   | 618        |
| 17.6.2.    | <i>Load linetypes</i> .....              | 618        |
| 17.6.3.    | <i>Orthogonal lines</i> .....            | 618        |
| 17.6.4.    | <i>Layers</i> .....                      | 618        |
| 17.6.5.    | <i>The left side elevation</i> .....     | 619        |
| 17.6.5.1.  | Miter line.....                          | 619        |
| 17.6.5.2.  | Ground and slab level.....               | 619        |
| 17.6.5.3.  | Windows .....                            | 620        |
| 17.6.5.4.  | Wall.....                                | 622        |
| 17.6.5.5.  | Roof .....                               | 622        |
| 17.6.5.6.  | Porch .....                              | 626        |
| <b>18.</b> | <b>SITE PLAN .....</b>                   | <b>629</b> |
| 18.1.      | LEARNING OBJECTIVES .....                | 629        |
| 18.2.      | INTRODUCTION.....                        | 630        |
| 18.3.      | TERMINOLOGY .....                        | 630        |
| 18.4.      | COMPONENTS OF A SITE PLAN .....          | 630        |
| 18.5.      | AUTOCAD AND SITE PLAN.....               | 631        |
| 18.5.1.    | <i>Open file</i> .....                   | 631        |
| 18.5.2.    | <i>Layers</i> .....                      | 633        |
| 18.5.3.    | <i>Units</i> .....                       | 633        |
| 18.5.4.    | <i>Load linetypes</i> .....              | 633        |
| 18.5.5.    | <i>Property line</i> .....               | 634        |
| 18.5.6.    | <i>North</i> .....                       | 635        |
| 18.5.7.    | <i>Ground slope</i> .....                | 635        |
| 18.5.8.    | <i>Setbacks</i> .....                    | 635        |
| 18.5.9.    | <i>Road</i> .....                        | 637        |
| 18.5.10.   | <i>Adjacent properties</i> .....         | 638        |
| 18.5.11.   | <i>Building</i> .....                    | 638        |
| 18.5.12.   | <i>Driveway</i> .....                    | 640        |
| 18.5.13.   | <i>Walkway</i> .....                     | 641        |
| 18.5.14.   | <i>Swimming pool</i> .....               | 643        |
| 18.5.15.   | <i>Utilities</i> .....                   | 647        |
| 18.5.16.   | <i>Template file</i> .....               | 648        |
| <b>19.</b> | <b>CONSTRUCTION DRAWINGS .....</b>       | <b>651</b> |
| 19.1.      | LEARNING OBJECTIVES .....                | 651        |
| 19.2.      | INTRODUCTION.....                        | 652        |
| 19.3.      | DRAWING FORMAT .....                     | 652        |
| 19.4.      | BLOCKS USED .....                        | 652        |
| 19.5.      | FAMILY OF CONSTRUCTION DRAWING .....     | 654        |
| 19.5.1.    | <i>Cover sheet</i> .....                 | 654        |

|            |   |            |
|------------|---|------------|
| 19.5.2.    | <i>General information</i> .....  | 654        |
| 19.5.3.    | <i>Quantity sheet</i> .....   | 654        |
| 19.5.4.    | <i>Survey or mapping</i> .....  | 655        |
| 19.5.5.    | <i>Soil information</i> .....   | 655        |
| 19.5.6.    | <i>Erosion control</i> .....  | 655        |
| 19.5.7.    | <i>Landscape drawings</i> .....   | 656        |
| 19.5.8.    | <i>Structural drawings</i> .....  | 656        |
| 19.5.9.    | <i>Fire protection drawings</i> .....   | 656        |
| 19.5.10.   | <i>Architectural drawings</i> .....   | 656        |
| 19.5.11.   | <i>Plumbing drawings</i> .....  | 656        |
| 19.5.12.   | <i>Mechanical drawings</i> .....  | 656        |
| 19.5.13.   | <i>Electrical drawings</i> .....  | 657        |
| 19.5.14.   | <i>Telecommunication drawings</i> .....   | 657        |
| 19.5.15.   | <i>Plan and profile drawings</i> .....  | 657        |
| <b>20.</b> | <b>PLOTTING FROM AUTOCAD 2018.....</b>  | <b>659</b> |
| 20.1.      | LEARNING OBJECTIVES .....   | 659        |
| 20.2.      | INTRODUCTION .....  | 660        |
| 20.3.      | PRINT  ..... | 660        |
| 20.3.1.    | <i>Plot dialog box</i> .....  | 662        |
| 20.3.1.1.  | Page setup .....  | 663        |
| 20.3.1.2.  | Printer/plotter.....  | 663        |
| 20.3.1.3.  | Paper size .....  | 664        |
| 20.3.1.4.  | Plot area .....   | 664        |
| 20.3.1.5.  | Plot offset.....  | 668        |
| 20.3.1.6.  | Plot scale.....   | 669        |
| 20.3.1.7.  | Shaded viewport options.....  | 669        |
| 20.3.1.8.  | Plot options .....  | 670        |
| 20.3.1.9.  | Drawing orientation .....   | 672        |
| 20.3.1.10. | Preview .....   | 672        |
| 20.3.1.11. | Plot to layout .....  | 673        |
| 20.3.1.12. | OK and cancel.....  | 673        |
| 20.4.      | PLOT FROM LAYOUTS.....  | 673        |
| 20.5.      | CHANGE LAYOUT'S ORIENTATION .....   | 675        |
| 20.6.      | PAGE SETUP FROM LAYOUTS .....   | 677        |
| 20.7.      | LAYOUT PLOTTING: FAQ.....   | 680        |
| 20.8.      | PORTABLE DOCUMENT FORMAT (PDF).....   | 680        |
| 20.9.      | OPTION DIALOG BOX .....   | 683        |
| <b>21.</b> | <b>SUGGESTED IN-CLASS ACTIVITIES.....</b>   | <b>685</b> |
| 21.1.      | INTRODUCTION .....  | 685        |
| 21.2.      | DOWNLOAD AUTOCAD 2018.....  | 686        |
| 21.3.      | CUSTOMIZE A WORKSPACE .....   | 687        |
| 21.4.      | GRID AND SNAP CAPABILITIES .....  | 688        |
| 21.5.      | ERASE, LINE, POLYLINE AND POLYLINE EDIT .....   | 690        |
| 21.6.      | POINT, CIRCLE, POLYGON, OFFSET, MOVE, TRIM, EXTEND, AND ZOOM .....                            | 691        |
| 21.7.      | COLOR, LINETYPE, LINEWEIGHT, MIRROR, COPY, SCALE, AND, HATCH .....                            | 695        |
| 21.8.      | ARRAY, TEXT, HATCH, ELLIPSE, QLEADER, AND DRAW ORDER.....                                     | 699        |
| 21.9.      | LAYERS .....  | 702        |
| 21.10.     | MAKE & INSERT BLOCK, LAYOUTS, AND TEMPLATE FILES.....   | 705        |
| 21.11.     | DIMENSION.....  | 707        |
| 21.12.     | AZIMUTHS, BEARING, AND CLOSED TRAVERS.....  | 708        |
| 21.13.     | RSS, LOTS AND BLOCKS .....  | 710        |
| 21.14.     | ROTATE, TEXT, BACKGROUND MASK, & TABLE COMMAND AND CONTOUR MAP.....                           | 713        |
| 21.15.     | DRAINAGE BASIN DELINEATION .....  | 714        |
| 21.16.     | FLOODPLAIN DELINEATION .....  | 715        |

|            |   |            |
|------------|---|------------|
| 21.17.     | ROAD DESIGN: PLAN AND PROFILE .....             | 716        |
| 21.18.     | ROAD DESIGN: CROSS-SECTION.....                 | 717        |
| 21.19.     | ROAD DESIGN: EARTHWORK.....                     | 718        |
| 21.20.     | FLOOR PLAN .....                                | 719        |
| 21.21.     | FLOOR PLAN (CONT.) .....                        | 720        |
| 21.22.     | FLOOR PLAN (CONT.) .....                        | 721        |
| 21.23.     | DIMENSIONS (ARCHITECTURAL DRAWING).....         | 722        |
| 21.24.     | ROOF PLAN .....                                 | 724        |
| 21.25.     | FRONT ELEVATION.....                            | 725        |
| 21.26.     | LEFT ELEVATION.....                             | 726        |
| 21.27.     | SITE PLAN .....                                 | 727        |
| <b>22.</b> | <b>HOMEWORK DRAWINGS .....</b>                  | <b>729</b> |
| 22.1.      | GRID-1 (UNITS: INCHES) .....                    | 729        |
| 22.2.      | GRID -2 (UNITS: MILLIMETERS) .....              | 730        |
| 22.3.      | LIGHT SIGNAL (UNITS: INCHES).....               | 731        |
| 22.4.      | PLATE WITH HOLES (UNITS: INCHES) .....          | 732        |
| 22.5.      | CIRCLE-TTR (UNITS: MILLIMETERS).....            | 732        |
| 22.6.      | PIER (UNITS: MILLIMETERS) .....                 | 733        |
| 22.7.      | SIMPLE SHAPE (UNITS: INCHES) .....              | 733        |
| 22.8.      | PIPE CUTTER (UNITS: MILLIMETERS).....           | 734        |
| 22.9.      | RECTANGULAR ARRAY (UNITS: INCHES) .....         | 734        |
| 22.10.     | ZOOM POLAR ARRAY (UNITS: INCHES).....           | 735        |
| 22.11.     | MIRROR, COPY, AND SCALE, (UNITS: INCHES) .....  | 736        |
| 22.12.     | SPIRAL OF ARCHIMEDES (UNITS: MILLIMETERS) ..... | 739        |
| 22.13.     | ELEVATOR SYSTEM (UNITS: MILLIMETERS) .....      | 741        |
| 22.14.     | FERRIS WHEEL (UNITS: MILLIMETERS) .....         | 745        |
| <b>23.</b> | <b>BIBLIOGRAPHY .....</b>                       | <b>749</b> |
| <b>24.</b> | <b>INDEX.....</b>                               | <b>753</b> |