AUTODESK.
Authorized Author

AutoCAD® 2016
INSTRUCTOR

James A. Leach

SDC PUBLICATIONS
Better Textbooks. Lower Prices.
www.SDCpublications.com

Visit the following websites to learn more about this book:

SDC Publications
amazon.com
Google books
BARNES&NOBLE

PREFACE....xvii

INTRODUCTION....xxiii

CHAPTER 1
GETTING STARTED....1
CONCEPTS....2
  Coordinate Systems....2
  The CAD Database....3
  Angles in AutoCAD....3
  Draw True Size....3
  Plot to Scale....5
STARTING AutoCAD....5
THE AutoCAD DRAWING EDITOR....6
  Beginning a Drawing....6
  Drafting & Annotation Workspace....7
  Command Entry Using the Keyboard....11
  Accelerator Keys (Control Key Sequences)....12
  Special Key Functions....12
  Mouse Buttons....12
COMMAND ENTRY....12
  Methods for Entering Commands....12
  Using the "Command Tables" in this Book to Locate a Particular Command....13
  Command Entry Methods Practice....13
  Line....13
DRAWING AIDS....15
  Status Bar....15
  Function Keys....20
  AutoCAD Text Window....20
  Model Space and Layouts....21
CUSTOMIZING THE AutoCAD SCREEN....22
  Toolbars....22
  Ribbon....23
  Clean Screen....24
  Options....25

CHAPTER 2
WORKING WITH FILES....27
AutoCAD DRAWING FILES....28
  Naming Drawing Files....28
  Beginning and Saving an AutoCAD Drawing....28
  Accessing File Commands....28
  File Navigation Dialog Box Functions....29
  Windows Right-Click Shortcut Menus....30
  New....31
AUTOCAD FILE COMMANDS....31
  Qnew....32
  Open....33
  Save....35
  Qsave....35
  Saveas....35
  Close....37
  Closeall....37
  Closeallother....37
  Exit....37
  Quit....38
  Partialopen....38
  Partiaload....39
  Recover....40
  Dwgprops....40
  SAVETIME....41
  AutoCAD Backup Files....42
  Drawing Recovery....42
  AutoCAD Drawing File Management....43
  Using Other File Formats....43

CHAPTER 3
DRAW COMMAND CONCEPTS....45
AutoCAD OBJECTS....46
LOCATING THE DRAW COMMANDS....46
COORDINATE ENTRY....48
  Coordinate Formats and Types....48
  Coordinate Formats....48
  Coordinate Types....48
  Typical Combinations....48
  Three Methods of Coordinate Input....48
  Mouse Input....49
  Dynamic Input....49
  Command Line Input....50
PRACTICE USING THE THREE COORDINATE INPUT METHODS....50
  Line....50
  Using Mouse Input to Draw Lines and Circles....51
  Circle....51
  Using *Dynamic Input* to Draw Lines and Circles....53
  Using Command Line Input to Draw Lines and Circles....55
  Direct Distance Entry and Angle Override....57
  Dynamic Input Settings....57
POLAR TRACKING AND *POLAR SNAP*....58
  Polar Tracking....58
  Polar Tracking with Direct Distance Entry....59
  Polar Tracking Override....60
  Polar Snap....60
DRAWING LINES USING *POLAR TRACKING*....61
  Using *Polar Tracking* and *Grid Snap*....61
  Using *Polar Tracking* and *Dynamic Input*....62
  Using *Polar Tracking*, *Polar Snap*, and *Dynamic Input*....63

CHAPTER 4

SELECTION SETS 69
MODIFY COMMAND CONCEPTS......................70
SELECTION SETS 70
  Selection Set Options 71
  Selection Cycling 76
  Select...76
NOUN/VERB SYNTAX..77
SELECTION SETS PRACTICE...............................77
  Using *Erase* 78
  Erase..78
  Using *Move* 79
  Move..79
  Using *Copy*...80
  Copy 80
  Noun/Verb Command Syntax Practice 81

CHAPTER 5

HELPFUL COMMANDS...........................85
CONCEPTS...86
  Help 86
  Oops 88
  U..88
  Undo..88
  Redo...90
  Mredo 90
  Regen...91

CHAPTER 6

BASIC DRAWING SETUP.......................93
STEPS FOR BASIC DRAWING SETUP 94
STARTUP OPTIONS..94
DRAWING TEMPLATES..95
  Table of Basic Settings for the ACAD (Inch) Templates 96
  Table of Basic Settings for the ACADISO (Metric) Templates..96
SETUP COMMANDS..97
  Units 97
  Keyboard Input of *Units* Values.......................98
  Limits 99
  Snap..101
  Grid 103
  Using *Snap* and *Grid*...104
  Dsettings 104
INTRODUCTION TO LAYOUTS AND PRINTING...105
  Model Tab and *Layout* Tabs 105
  Why Set Up Layouts Before Drawing? 108
  Printing and Plotting 108
  Setting Layout Options and Plot Options.....109

CHAPTER 7

OBJECT SNAP AND OBJECT SNAP TRACKING...113
CAD ACCURACY...114
OBJECT SNAP...114
OBJECT SNAP MODES 115
  Acquisition Object Snap Modes 118
  Object Snap Modifiers.....................................120
OBJECT SNAP SINGLE POINT SELECTION ...121
  Object Snaps (Single Point) 121
OBJECT SNAP RUNNING MODE 123
  Running Object Snap Modes 123
  Osnap 123
  Running Object Snap Toggle 124
  Object Snap Options 124
OBJECT SNAP TRACKING 127
  To Use Object Snap Tracking: 128
  Object Snap Tracking with Polar Tracking ...128
  Object Snap Tracking Settings 130

CHAPTER 8

DRAW COMMANDS I........................ 137
CONCEPTS...138
  Draw Commands—Simple and Complex 138
  Draw Command Access 138
  Coordinate Entry Input Methods..................139
COMMANDS 139
  Line...139
  Circle 140
  Arc..142
  Use *Arcs* or *Circles?*...146
  Point 147
  Ptype 147
  Pline 148
  Pline Arc Segments 150

CHAPTER 9

MODIFY COMMANDS I 155
CONCEPTS...156
COMMANDS 157
  Erase...157
  Move...158
  Rotate 159
  Scale...161
  Stretch 162
  Lengthen..163
  Trim 165
  Extend 167
  Trim and *Extend* Shift-Select Option 168
  Break...169
  Join 170

Copy 171
Mirror 173
Offset 174
Array 176
Arrayrect 177
Creating and Editing Arrays Using Grips 178
Arraypolar 178
Arraypath 181
Fillet 183
Chamfer 185

CHAPTER 10 VIEWING COMMANDS 197

CONCEPTS 198
ZOOM AND *PAN* WITH THE MOUSE WHEEL 199
Zoom and *Pan* 199
Zoom with the Mouse Wheel 199
Pan with the Mouse Wheel 200
COMMANDS 201
Zoom 201
Pan 205
Zoom and *Pan* with *Undo* and *Redo* 206
Viewback 206
Viewforward 206
View 206
Viewres 208
Ucsicon 209
Viewgo 210
Qvdrawing 210
Vports 211

CHAPTER 11 LAYERS AND OBJECT PROPERTIES 217

CONCEPTS 218
Assigning Colors, Linetypes, Lineweights, and Transparency 218
Object Properties 219
Plot Styles 219
LAYERS AND LAYER PROPERTIES CONTROLS 220
Layer Drop-Down List 220
Layer 220
Layer Properties Manager Layer List 221
Color, Linetype, Lineweight, and Other Properties 223
Layer Filters 225
Displaying an Object's Properties and Visibility Settings 227
Laymcur 228
Layerp 228
Layerstate 228
OBJECT-SPECIFIC PROPERTIES CONTROLS 231
Linetype 231
Linetype Drop-Down List 233
Lweight 233
Lineweight Drop-Down List 234
Color 235
Color Drop-Down List 236
True Color and *Color Books* 236
Setbylayer 237
CONTROLLING LINETYPE SCALE 238
LTSCALE 238
CELTSCALE 239
CHANGING OBJECT PROPERTIES 240
Properties Panel 240
Properties 241
Matchprop 241
LAYER TOOLS 242
Laymch 242
Laycur 243
Layiso 243
Layuniso 245
Copytolayer 245
Laywalk 246
Layfrz 249
Laythw 250
Layoff 250
Layon 250
Laylck 251
Layulk 251
Layvpi 251
Laymrg 252
Laydel 253

CHAPTER 12 ADVANCED DRAWING SETUP 259

CONCEPTS 260
STEPS FOR DRAWING SETUP 260
USING AND CREATING TEMPLATE DRAWINGS 264
Using Template Drawings 264
Table of Standard AutoCAD Templates 265
Creating Template Drawings 266
Additional Advanced Drawing Setup Concepts 267
Steps for Drawing Setup Using Annotative Objects 267

CHAPTER 13 LAYOUTS AND VIEWPORTS 271

CONCEPTS 272
Paper Space and Model Space 272

Layouts....272
Viewports....273
Layouts and Viewports Example....275
Guidelines for Using Layouts and Viewports....278
CREATING AND SETTING UP LAYOUTS....279
Layoutwizard....279
Layout....281
Inserting Layouts with AutoCAD DesignCenter....283
Setting Up the Layout....283
Options....284
Pagesetup....285
Psetupin....286
USING VIEWPORTS IN PAPER SPACE....287
Vports....287
Qvlayout....290
Scaling the Display of Viewport Geometry....291
Locking Viewport Geometry....293
Linetype Scale in Viewports—*PSLTSCALE*....293
Vpmax....294
Vpmin....295
Scalelistedit....295
Chspace....296
Advanced Applications of Paper Space Viewports....297

CHAPTER 14
PRINTING AND PLOTTING....307
CONCEPTS....308
TYPICAL STEPS TO PLOTTING....308
PRINTING, PLOTTING, AND SAVING PAGE SETUPS....309
Plot....309
-Plot....314
Viewplotdetails....314
Pagesetup....315
Should You Use the *Plot* Dialog Box or the *Page Setup Manager*?....317
PLOTTING TO SCALE....318
Preview....318
Standard Paper Sizes....319
Calculating the Drawing Scale Factor....319
Guidelines for Plotting Model Space to Scale....320
Guidelines for Plotting Layouts to Scale....320
TABLES OF *LIMITS* SETTINGS....321
Examples for Plotting to Scale....327
CONFIGURING PLOTTERS AND PRINTERS....328
Plotting Components....328
Plottermanager....328
Add-A-Plotter Wizard....329
Plotter Configuration Editor....330

CHAPTER 15
DRAW COMMANDS II....335
CONCEPTS....336
COMMANDS....336
Xline....336
Ray....338
Polygon....339
Rectang....340
Donut....341
Spline....342
Ellipse....344
Divide....346
Measure....347
Mline....348
Multiline Style Dialog Box....350
Mlstyle....350
New Multiline Style Dialog Box....351
Multiline Styles Example....352
Editing Multilines....353
Sketch....353
Solid....355
Boundary....355
Region....356
Wipeout....358
Revcloud....358

CHAPTER 16
MODIFY COMMANDS II....365
CONCEPTS....366
COMMANDS....366
Considerations for Changing Basic Properties of Objects....367
Properties....368
Dblclkedit....371
Matchprop....372
Object Properties Drop-Down Lists....373
Quick Properties....374
Chprop....374
Change....374
Explode....375
Align....376
Pedit....377
Vertex Editing....380
Editing *Plines* with Grips....382
Editing *Spline* Fit Data Points....383
Splinedit....383
Editing *Spline* Control Vertices....385
Editing *Splines* with Grips....386
Reverse....387
Blend....387
Arrayedit....388
Mledit....390

Overkill 394
Boolean Commands 395
Union 396
Subtract 396
Intersect 397
Modifying *Revclouds* 398

CHAPTER 17
INQUIRY COMMANDS 405
CONCEPTS 406
COMMANDS 406
Status 406
List 407
Measuregeom 408
Id 411
Time... 411
Setvar 412
Sysvarmonitor 413
Massprop 414

CHAPTER 18
TEXT AND TABLES 417
CONCEPTS 418
TEXT CREATION COMMANDS 420
Text 420
Mtext 423
Bullets and Lists 430
Creating Stacked Text 430
Creating Columns 431
Calculating Text Height for Scaled Drawings 432
Spacetrans 433
TEXT STYLES, FONTS, ANNOTATIVE TEXT, AND EXTERNAL TEXT 434
Style 434
Annotative Text 437
Importing External Text into AutoCAD 440
Using an External Text Editor for *Multiline Text* 440
Format Codes for Creating *Multiline* Text in External Text Editors 441
EDITING TEXT 442
Textedit 443
Mtedit 443
Properties 443
Spell 444
Find 445
Find/Replace in the *Text Editor* tab 447
Scaletext 447
Justifytext 449
Qtext 450
TEXTFILL 451
Substituting Fonts 451
TEXT FIELDS AND TABLES 452
Text Fields 452
Field 453
Creating and Editing Tables 454
Updatefield 454
Table 455
Tablestyle 456
The *Table Cell* Editor 458
Tabledit 458
Editing Tables with Grips 460
Editing Tables with the *Properties* Palette 460
Importing and Exporting Tables 461
Table Breaks 462
Text Fields and Calculations in Tables 462
Text Attributes 465

CHAPTER 19
GRIP EDITING 471
CONCEPTS 472
GRIPS FEATURES 472
Activating Grips on Objects 473
Cold and Hot Grips 473
GRIPS System Variable Settings 474
Grips Menus 474
Grip Editing Options 475
Shift to Turn on *Ortho* 477
Auxiliary Grid 477
Editing Dimensions 477
Multifunctional Grips 478
GUIDELINES FOR USING GRIPS 478
GRIPS SETTINGS 479
Point Specification Precedence 480
More Grips 481

CHAPTER 20
ADVANCED SELECTION SETS 485
CONCEPTS 486
SELECTION SET VARIABLES 486
Changing the Settings 486
Options 487
OBJECT SELECTION TOOLS AND FILTERS 489
Selall 489
Selectsimiliar 489
Hideobjects 490
Unisolateobjects 491
Isolateobjects 491
Qselect 491
Filter 494
OBJECT GROUPS 497
Group 498
Groupedit 499

  - *Ungroup* 499
  - Group Examples 500
  - *Classicgroup* 501
  - Changing Properties of a Group 503

CHAPTER 21 BLOCKS, DESIGNCENTER, AND TOOL PALETTES 509

- CONCEPTS 510
- COMMANDS 512
  - *Block* 512
  - *Block Color, Linetype,* and *Lineweight* Settings 513
  - *Insert* 514
  - *Minsert* 515
  - *-Insert* with * 516
  - *Explode* 516
  - *Xplode* 517
  - *Wblock* 518
  - Redefining Blocks and the Block Editor 520
  - *Base* 520
  - *Bedit* 521
  - *Blocks* Search Path 523
  - *Purge* 523
  - *Rename* 525
- DESIGNCENTER 526
  - *Setbylayer* 526
  - *Adcenter* 527
  - DesignCenter Options 528
  - To Open a Drawing from DesignCenter 532
  - To *Insert* a *Block* Using DesignCenter 533
- TOOL PALETTES 535
  - *Toolpalettes* 535
  - Creating and Managing Tool Palettes 537

CHAPTER 22 BLOCK ATTRIBUTES AND DATA LINKS 545

- CONCEPTS 546
- CREATING ATTRIBUTES 546
  - Steps for Creating and Inserting Block Attributes 546
  - *Attdef* 547
  - Saving the Attributed Block 551
  - *Inserting* Attributed Blocks 551
  - The *ATTDIA* Variable 552
  - The *ATTREQ* Variable 552
- DISPLAYING AND EDITING ATTRIBUTES 552
  - *Attdisp* 552
  - *Attedit* 553
  - Multiple Attedit 554
  - *Eattedit* 554
  - *Properties* 555
  - *Find* 556
  - *-Attedit* 557
  - Global and Individual Editing Example 559
- REDEFINING ATTRIBUTES 562
  - *Battman* 563
  - *Attredef* 565
  - *Refedit, Properties,* and *Refclose* 566
  - The Block Editor 567
  - Grip Editing Attribute Location 568
- EXTRACTING ATTRIBUTES 568
  - *Attsync* 568
  - *Eattext* 569
  - Updating Attribute Data 573
  - *Datalink* 574
  - Data Link Examples 575
  - *Datalinkupdate* 577

CHAPTER 23 INTERNET TOOLS AND COLLABORATION 583

- CONCEPTS 584
  - *Browser* 585
  - Autodesk Exchange 586
  - *Inetlocation* 586
  - Autodesk 360® and AutoCAD 360® 587
  - *Onlineshare* 588
  - *Onlineopenfolder* 589
  - *Onlinedocs* 589
  - *Onlinesync* 590
  - *Onlinesyncsettings* 590
  - *Onlineautocad360* 591
- USING HYPERLINKS 592
  - *Hyperlink* 592
- CREATING EMAIL AND WEB PAGES 594
  - Hyperlinkbase 594
  - *Selecturl* 594
  - *Publishtoweb* 594
  - *Etransmit* 597
  - Transmittal Setups 598
  - *Modify Transmittal Setup* Dialog Box 599
- CREATING .DWF AND .PDF FILES 600
  - Raster Files and Vector Files 601
  - Creating .DWF and .PDF Files with ePlot and Export 602
  - *Exportpdf* 602
  - *Exportdwf* 603
  - ePlot Options 604
  - Creating .DWF and .PDF Files with *Publish* 604
  - *Publish* 604
- VIEWING .DWF AND .PDF FILES 607

Autodesk Design Review 607
DWF Underlay and *PDF Underlay* in AutoCAD 609
Dwfattach 609
Dwfclip 611
To Detach a DWF or PDF Underlay..............612
Viewing URLs (Hyperlinks) in a .DWF Image 612
Dwflayers 612
MARKUP SET MANAGER.................................613
The Markup Tools 613
The Markup Process...613
Markups in AutoCAD 614
Opendwfmarkup 614
Markup..614
TRANSFERRING AUTOCAD FILES OVER THE INTERNET..615
Opening and Saving .DWF and .DWG Files via the Internet..................................615
Using i-drop to Drag-and-Drop Drawing Files into AutoCAD 616

CHAPTER 24
MULTIVIEW DRAWING 621
CONCEPTS..622
PROJECTION AND ALIGNMENT OF VIEWS 622
Using *Ortho* and *Object Snap* to Draw Projection Lines..622
Using *Polar Tracking* to Draw Projection Lines..623
Using *Object Snap Tracking* to Draw Projection Lines Aligned with *Object Snap* Points 624
Using *Xline* and *Ray* for Construction Lines 626
Using *Offset* for Construction of Views 626
Realignment of Views Using *Polar Snap* and *Polar Tracking*.......................................627
USING CONSTRUCTION LAYERS 627
USING LINETYPES..628
Drawing Hidden and Center Lines 629
Managing Linetypes, Lineweights, and Colors 630
CREATING FILLETS, ROUNDS, AND RUNOUTS..631
GUIDELINES FOR CREATING A TYPICAL THREE-VIEW DRAWING..............................633

CHAPTER 25
PICTORIAL DRAWINGS 641
CONCEPTS..642
Types of Pictorial Drawings............................642
Pictorial Drawings Are 2D Drawings............643
ISOMETRIC DRAWING IN AUTOCAD............644
Snap..644
Isometric Ellipses..646
Ellipse..646
Creating an Isometric Drawing......................648
Dimensioning Isometric Drawings in AutoCAD 650
OBLIQUE DRAWING IN AUTOCAD...............650
Isometric Drawing...652
Oblique Drawing...654

CHAPTER 26
SECTION VIEWS 655
CONCEPTS..656
DEFINING HATCH PATTERNS AND HATCH BOUNDARIES................................656
Steps for Creating a Section View Using the *Hatch* Command 657
Hatch..658
Pattern Panel...659
Properties Panel..659
Boundaries Panel (Selecting the Hatch Area).661
Origin Panel...663
Options Panel...663
Hatch and Gradient Dialog Box........................665
Gradient Hatches..666
-Hatch Command Line Options......................667
Creating Tool Palettes 671
Toolpalettes...671
EDITING HATCH PATTERNS AND BOUNDARIES...673
Hatchedit..673
Using Grips with Hatch Patterns..674
Using *Trim* with Hatch Patterns 674
Object Selection Features of Hatch Patterns.674
FILLMODE for Solid *Hatch* Fills.....................675
Draworder 676
Texttofront..676
DRAWING CUTTING PLANE LINES 677

CHAPTER 27
AUXILIARY VIEWS 683
CONCEPTS..684
CONSTRUCTING AN AUXILIARY VIEW........684
Setting Up the Principal Views.......................684
Using *Snap Rotate* and *Ortho* 685
Rotating *Snap* Back to the Original Position.686
Using *Polar Tracking*..688
Using the *Offset* Command 689
Offset 690
Using the *Xline* and *Ray* Commands 691
Xline 691

Ray 691
Constructing Full Auxiliary Views 692

CHAPTER 28

DIMENSIONING **697**
CONCEPTS 698
Dimension Components 698
Dimension Placement 698
Associativity 699
Accessing Dimension Commands 699
DIMENSION DRAWING COMMANDS 700
Dim 700
Dimlinear 700
Dimaligned 703
Dimbaseline 704
Dimcontinue 705
Dimspace 706
Dimangular 707
Dimdiameter 708
Dimradius 709
Dim 711
Dimjogline 715
Dimjogged 716
Dimarc 716
Dimcenter 717
Dimbreak 718
Leader 719
Qleader 720
Mleader 723
Mleaderstyle 724
Mleaderedit 727
Mleaderalign 728
Mleadercollect 729
Dimordinate 730
Qdim 732
Tolerance 735
Editing Feature Control Frames 737
Basic Dimensions 737
GDT-Related Dimension Variables 738
Geometric Dimensioning and Tolerancing Example 738
Diminspect 742
EDITING DIMENSIONS 743
Grip Editing Dimensions 743
Multifunctional Grips 745
Exploding Associative Dimensions 746
Dimension Editing Commands 746
Dimtedit 746
Dimedit 747
Properties 748
Customizing Dimensioning Text 749
Associative Dimensions 750
Dimreassociate 752
Dimdisassociate 753
DIMENSIONING VARIABLES INTRODUCTION 754
Dimregen 754

CHAPTER 29

DIMENSION STYLES AND VARIABLES **759**
CONCEPTS 760
Dimension Variables 760
Dimension Styles 761
Dimension Style Families 761
Dimension Style Overrides 763
DIMENSION STYLES 763
Dimstyle or Ddim 763
-Dimstyle 767
DIMENSION VARIABLES 768
Changing Dimension Variables Using the Dialog Box Method 769
Lines Tab 769
Dimension Lines Section (*Lines* Tab) 769
Extension Line Section (*Lines* Tab) 771
Symbols and Arrows Tab 772
Arrowheads Section (*Symbols and Arrows* Tab) 772
Other Sections (*Symbols and Arrows* Tab) 773
Text Tab 774
Text Appearance Section (*Text* Tab) 775
Text Placement Section (*Text* Tab) 776
Text Alignment Section (*Text* Tab) 777
Fit Tab 777
Scale for Dimension Features Section (*Fit* Tab) 778
Fit Options Section (*Fit* Tab) 778
Text Placement Section (*Fit* Tab) 780
Fine Tuning Section (*Fit* Tab) 780
Primary Units Tab 781
Linear Dimensions Section (*Primary Units* Tab) 782
Measurement Scale Section (*Primary Units* Tab) 783
Zero Suppression Section (*Primary Units* Tab) 784
Angular Dimensions Section (*Primary Units* Tab) 784
Alternate Units Tab 784
Alternate Unit Section (*Alternate Units* Tab) ..785
Zero Suppression Section (*Alternate Units* Tab) 786
Placement Section (*Alternate Units* Tab) 786
Tolerances Tab 786
Tolerance Format Section (*Tolerances* Tab) 786
Alternate Unit Tolerance Section (*Tolerances* Tab) 788
DIMCONTINUEMODE 788

Changing Dimension Variables Using the Command Line Format....788
Dim... (variable name)....788
DIMASSOC (Associative Dimensions)....789
MODIFYING EXISTING DIMENSIONS....790
Modifying a Dimension Style....790
Creating Dimension Style Overrides and Using *-Dimstyle*, *Apply* (*Update)*....791
Properties....791
-Dimstyle....791
Apply....791
Dimoverride....792
Matchprop....793
Dimension Right-Click Menu....794
GUIDELINES FOR NON-ANNOTATIVE DIMENSIONING IN AUTOCAD....795
Strategy 1. Dimensioning a Single Drawing....795
Strategy 2. Creating Dimension Styles as Part of Template Drawings....797
Optional Method for Fixed Dimension Text Height in Template Drawings....797
DIMENSIONING IN PAPER SPACE LAYOUTS....798
When to Dimension in Paper Space....799
Procedure for Dimensioning in Paper Space....799
DIMENSIONING ISOMETRIC DRAWINGS....803

CHAPTER 30
XREFERENCES....811
CONCEPTS....812
An *Xref* Example....816
CREATING AND USING *XREFS*....818
Xref or External-references....819
Dependent Objects and Names....824
Evaluating New Layers....826
Xattach....828
Xbind....828
Adcenter....829
VISRETAIN....831
Xclip....831
XCLIPFRAME....833
Demand Loading....834
INDEXCTL....834
XLOADCTL....835
XREFOVERRIDE....837
EDITING FOR *XREFS* AND *BLOCKS*....837
XLOADPATH....837
Xopen....838
In-Place *Xref* and *Block* Editing....839
Refedit....840
Using *-Refedit* at the Command Line....842
Refset....842
Refclose....843
XEDIT....843
XFADECTL....844
XREFNOTIFY....844
MANAGING *XREF* DRAWINGS....845
PROJECTNAME....845
Reference Manager....847
XREFCTL....847

CHAPTER 31
OBJECT LINKING AND EMBEDDING (OLE)....855
CONCEPTS....856
Cut and Paste Between AutoCAD Drawings....856
Cut and Paste Between AutoCAD and Other Windows Applications (OLE)....857
The Windows Clipboard....859
OLE RELATED COMMANDS....860
Copyclip....861
Copybase....862
Copylink....862
Cutclip....863
Pasteclip....863
Pasteorig....865
Pasteblock....865
Pastespec....866
Insertobj....868
Pasteashyperlink....869
MANAGING OLE OBJECTS....870
Olelinks....870
OLE Right-Click Shortcut Menu....871
Olescale....871
Oleopen....871
Other AutoCAD Commands with OLE Objects....872
OLE-RELATED SYSTEM VARIABLES....873
MSOLESCALE....873
OLEHIDE....873
OLEQUALITY....873
OLESTARTUP....873

CHAPTER 32
ADVANCED LAYOUTS, ANNOTATIVE OBJECTS, AND PLOTTING....877
CONCEPTS....878
ADVANCED LAYOUTS....878

Layer Visibility for Viewports 879
Layer........880
Vplayer........882
Layer Property Overrides 885
Linetype Scale in Viewports 888
Psltscale........888
Dimensioning in Paper Space........890
The "Reverse Method" for Calculating Drawing Scale Factor 892
Steps for Calculating the Drawing Scale Factor by the "Reverse Method" 893
ANNOTATIVE OBJECTS........894
Setting Annotation Scale and Viewport Scale 894
Creating and Displaying Annotative Objects in Multiple Viewports........896
SELECTIONANNODISPLAY........898
Adding and Deleting Scale Representations for Annotative Objects 898
Objectscale........898
Adjusting Positions for Individual Annotative Object Scale Representations 900
ANNOALLVISIBLE........902
Annoreset........902
Annoupdate 903
SAVEFIDELITY........904
Linetype Scales for Annotative Drawings........904
MSLTSCALE........905
Applications for Multiple Viewports 906
Using Two Layouts to Plot the Same Geometry at Different Scales........906
Using Two Viewports to Display the Same Geometry at Different Scales........908
Using One Layout to Plot ***Xref*** Drawings in Multiple Viewports at Different Scales........910
PLOT STYLE TABLES AND PLOT STYLES 911
What is the Difference between a Plot Style and a Plot Style Table? 912
Color-Dependent and Named Plot Style Tables........914
Attaching a Plot Style Table to a Layout........915
Creating a Plot Style Table 916
Stylesmanager........916
Editing Plot Styles 917
Assigning Named Plot Styles to Objects........919
Plotstyle........921
Named Plot Style Table Example........922
Convertpstyles........924
PLOT STAMPING........925
Convertctb........925
Plotstamp 925

CHAPTER 33
3D BASICS, NAVIGATION, AND VISUAL STYLES 937

SETTING UP AUTOCAD TO DRAW IN 3D 938
Setting Up a Workspace........938
Activating the Acad3D or Acadiso3D Drawing Template 939
TYPES OF 3D MODELS........940
Wireframe Models........940
Surface Models........941
Solid Models........942
3D COORDINATE ENTRY........944
3D Coordinate Entry Formats 944
COORDINATE SYSTEMS........949
The World Coordinate System (WCS) and WCS Icon........950
User Coordinate Systems (UCS) and Icons ..950
The Right-Hand Rule........951
Ucsicon........952
3D NAVIGATION AND VIEW COMMANDS..954
Pan 955
Zoom 956
Navvcube........956
3D Orbit Commands........960
3Dorbit 961
3Dforbit........962
3Dcorbit 964
PERSPECTIVE 964
3Ddistance........965
View Presets 966
View........968
Adjusting the Amount of Perspective........970
3Dclip........971
Camera 972
Editing Camera Settings........974
3Dswivel 975
Navswheel 975
SteeringWheel Shortcut Menu........976
SteeringWheel Navigation Tools........977
SteeringWheel Settings........979
-Vpoint 980
Vpoint 981
Plan 982
Grid 982
Vports........983
VISUAL STYLES 985
Default Visual Styles........986
Vscurrent 986
Face Settings 990
Shadow Settings 992

- Edge Effects ... 993
- *Visualstyles* ... 994
- Graphics Performance Tuning ... 999
- *Shade, SHADEDIF, SHADEDGE* ... 1000
- *Render* ... 1000
- Printing 3D Models ... 1001

CHAPTER 34

USER COORDINATE SYSTEMS ... 1011

- CONCEPTS ... 1012
- CREATING AND MANAGING USER COORDINATE SYSTEMS ... 1012
  - *Ucs* ... 1013
  - *Dducsp* ... 1019
  - *Ucsman* ... 1020
  - ViewCube *UCS* Drop-Down List ... 1021
- UCS SYSTEM VARIABLES ... 1022
  - *Ucsbase* ... 1022
  - *Ucsview* ... 1022
  - *UcsOrtho* ... 1022
  - *Ucsfollow* ... 1024
  - *Ucsvp* ... 1024
  - *UCS3DPERPDISPLAYSETTING* ... 1025
  - *UCS3DPARADISPLAYSETTING* ... 1025
  - *UCSSELECTMODE* ... 1025
  - *Ucsaxisang* ... 1025
- USER COORDINATE SYSTEMS AND 3D MODELING ... 1026
  - Dynamic User Coordinate Systems ... 1026

CHAPTER 35

SOLID MODELING CONSTRUCTION ... 1029

- CONCEPTS ... 1030
  - Solid Model Construction Process ... 1030
  - Solid Primitives Commands ... 1030
  - Dynamic User Coordinate Systems ... 1031
  - Commands to Move, Rotate, Mirror, and Scale Solids ... 1031
  - Boolean Operations ... 1031
- SOLID PRIMITIVES COMMANDS ... 1033
  - *Box* ... 1034
  - *Cone* ... 1035
  - *Cylinder* ... 1037
  - *Wedge* ... 1038
  - *Sphere* ... 1039
  - *Torus* ... 1040
  - *Pyramid* ... 1040
  - *Polysolid* ... 1042
  - *Extrude* ... 1044
  - *Revolve* ... 1046
  - *Sweep* ... 1047
  - *Loft* ... 1049
- DYNAMIC USER COORDINATE SYSTEMS ... 1052
- COMMANDS TO MOVE, ROTATE, MIRROR, AND SCALE SOLIDS ... 1053
  - *Move* ... 1054
  - *3Dalign* ... 1055
  - *3Dmove* ... 1056
  - *3Dscale* ... 1058
  - *3Drotate* ... 1058
  - *Mirror3D* ... 1060
  - *3Darray* ... 1062
- BOOLEAN OPERATION COMMANDS ... 1065
  - *Union* ... 1065
  - *Subtract* ... 1066
  - *Intersect* ... 1067
  - *Chamfer* ... 1068
  - *Fillet* ... 1070
- DESIGN EFFICIENCY ... 1071

CHAPTER 36

SOLID MODEL EDITING ... 1083

- CONCEPTS ... 1084
- EDITING PRIMITIVES USING THE *PROPERTIES* PALETTE ... 1084
  - Editing *Properties* of Individual Primitives ... 1084
  - Composite Solid Subobject Selection ... 1086
  - Editing *Properties* of Composite Solids ... 1087
- EDITING SOLIDS USING GRIPS AND GIZMOS ... 1087
  - Move, Rotate, and Scale Gizmos ... 1093
  - Grip Editing Composite Solids ... 1095
  - Subobjects and Selection ... 1096
  - Grip Editing Faces, Edges, and Vertices ... 1097
  - Selecting Overlapping Subobjects ... 1101
  - History Settings ... 1101
- SOLIDS EDITING COMMANDS ... 1103
  - *Solidedit* ... 1104
  - *Face* Options ... 1105
  - *Edge* Options ... 1112
  - *Body* Options ... 1113
  - *Slice* ... 1116
  - *Presspull* ... 1117
  - *Sectionplane* ... 1119
  - *Sectionplane* Contextual Tab ... 1123
  - *Section Settings* Dialog Box ... 1125
  - *Interfere* ... 1125
  - *Imprint* ... 1127
  - *Massprop* ... 1128
- USING SOLIDS DATA ... 1128
  - *Stlout* ... 1129
  - *3Dprint* ... 1130
  - *Acisin* ... 1130
  - *Acisout* ... 1130

CHAPTER 37
2D DRAWINGS FROM 3D MODELS 1137
CONCEPTS 1138
COMMANDS 1139
Viewbase 1139
Viewbase Options 1143
Viewedit 1145
Drawing View Editing 1146
Viewproj 1147
Viewstd 1148
Viewsection 1149
Section View Examples 1151
Viewsectionstyle 1155
Modify Section View Style and *New Section View Style* Dialog Boxes 1156
Section View Style and *Detail View Style* Issues 1159
Viewcomponent 1160
Viewdetail 1161
Viewdetailstyle 1163
Modify Detail View Style and *New Detail View Style* Dialog Boxes 1164
Viewupdate 1166
Viewupdateauto 1168
Viewsymbolsketch 1168
Creating Auxiliary Views Using *Viewsection* 1169
Dimensioning a Documentation Drawing . 1171

APPENDIX A 1179
AutoCAD 2016 Command Alias List Sorted by Command 1180

APPENDIX B 1185
BUTTONS AND SPECIAL KEYS 1186
Mouse and Digitizing Puck Buttons 1186
Function (F) Keys 1186
Control Key Sequences (Accelerator Keys) 1187
Special Key Functions 1188

APPENDIX C 1189
Command Table Index 1190

INDEX 1215

CHAPTER EXERCISE INDEX 1235